

# FLEETIO INTEGRATION GUIDE

**ELD Rider is integrated with Fleetio - a premium fleet maintenance software.**

This integration will simplify the entire maintenance process by saving our users time and money along the way. Users will have access to DTC faults, odometer updates, vehicle location, fuel entry location, and other essential data. Once you set up the integration, our app will automatically send all relevant information to your Fleetio account.

## **Set-Up Process**

Mutual users of ELD Rider and Fleetio should contact our DA team with their integration request by sending an email to [dea@eldrider.com](mailto:dea@eldrider.com).

In the integration process, it is necessary to generate the **API Key and Account Token** in the Fleetio application. You can do that by clicking on **User Profile → Manage API Keys → Add API Key**. After the mentioned data is generated, our DA team will take over the rest of the work and make the necessary changes to the database for you.